
Lab 2: DNS

Module Leader: Dr. Amal ElNahas
Teaching Assistants: Noran AboDoma
Sarah Akram



DHCP, DNS & HTTP...


We'll start our lab with three protocols we'll be using for the day...

DHCP: Dynamic Host Configuration Protocol is a framework for automatically passing configuration information to hosts on a TCP/IP network.

DNS: Domain Name System (or Service, or Server) is an internet service that translates domain names into IP addresses.

HTTP: Hypertext Transfer Protocol is the underlying protocol used by the World Wide Web, which defines how messages are formatted and transmitted.

DNS Experiment



*Let's create
this network
and then we'
ll show you
how to
configure it
step-by-step.*

Connect End devices to Switches using straight-through cables. Connect Switch to Switch using Cross-Over cable.

DNS Experiment

1) Switch to Realtime mode.

2) Configure DHCP server:

Global Settings:

Display Name: "DHCP Server"

Gateway: 172.16.0.1

Fast Ethernet:

IP Address: 172.16.0.10

Subnet Mask: 255.255.0.0

HTTP: Set HTTP and HTTPS services to OFF.

DHCP:

Gateway: 172.16.0.1

DNS Server: 172.16.0.11

Start IP Address: 172.16.0.100

DNS: Set the server to OFF.

DNS Experiment

3)Configure DNS Server

Global Settings:

Display Name: “DNS Server”

Gateway: 172.16.0.1

Fast Ethernet:

IP Address: 172.16.0.11

Subnet Mask: 255.255.0.0

DHCP: Set the service to OFF

HTTP: Set HTTP and

HTTPS services to OFF

DNS: Set to ON

Entering the www.tsrb.edu

*Enter Domain Name www.tsrb.edu

*Enter IP Address 172.16.0.20

*Click Add

Entering the www.internal.com

*Enter Domain Name www.internal.com

*Enter IP Address 172.16.0.30

*Click Add

DNS Experiment

4)Configuring the www.tsrb.edu Web Server

Global Settings:

Display Name: “Web Server: www.tsrb.edu”

Gateway: 172.16.0.1

HTTP:

Fast Ethernet:

IP Address: 172.16.0.20

Change the sentence to

<hr> Welcome to Tsrb’s public web page!

Subnet Mask: 255.255.0.0

DHCP: Set the service to OFF

DNS: Set the Service to OFF

DNS Experiment

5)Configuring the www.internal.com Web Server

Global Settings:

Display Name: “Web Server: www.internal.com”

Gateway: 172.16.0.1

HTTP:

Fast Ethernet:

Change the sentence to

IP Address: 172.16.0.30

<hr> This is the corporate internal network!

Subnet Mask: 255.255.0.0

DHCP: Set the service to OFF

DNS: Set the Service to OFF

DNS Experiment

6) Configure two Client computers using DHCP

Global Settings:

Display Name “Dynamic 1” and “Dynamic 2”

Set the Gateway/DNS to DHCP

Fast Ethernet: Set the IP Configuration to DHCP

DNS Experiment

7)Configure One Client computer using Static IP Addressing

Global Settings:

Display Name: “Static”

Set the Gateway/DNS to Static

Gateway: 172.16.0.1

DNS Server 172.16.0.11

Fast Ethernet:

Set the configuration to Static

IP Address: 172.16.0.90

Subnet Mask: 255.255.0.0

DNS Experiment

Now, that the network is configured, let's verify its connectivity

PING (ICMP)

From a client computer use the Desktop > Command prompt to ping the other client computers and the servers

Example: From Dynamic one client: ping 172.16.0.20

Browser (HTTP)

On the client computers use the Desktop > Web Browser, enter the URLs of the Web Servers www.tsrb.edu & www.internal.com.

DNS Experiment

Using the Simulation Mode

Click on Edit Filters > Choose Show All/None and select the following protocols: DHCP, ICMP, HTTP, DNS

Web Browser (HTTP): use Desktop > Web Browser, enter any of the URLs and Click on Auto Capture/Play

DHCP: Click on Reset Simulation

To view DHCP on one of the Dynamic client computers open Desktop Command Prompt and enter “ipconfig /all”

To have the client computer ask for a new IP address enter “ipconfig /renew”

DNS: Enter in the Command Prompt “nslookup” to know the local DNS server.

This was all for today.
Thank you!
